

BROKEN LIGHT BULB REMOVER



This product is to be used solely for the purpose intended with the correct size light bulb, which is either a **BR30** size or **BR20** size, High Hat Light Bulb, depending on which product you purchased.

PLEASE NOTE: Before use, you **must** turn off any and all power to the light fixture to avoid any possibility of shock hazard or worse.

This is best accomplished by turning off the light switch which connects to the light fixture, and turning off power to that light fixture and its related switch from the “Breaker Box”. Before moving on, you should confirm multiple times, that the power has indeed been turned off to that light switch and light fixture.

Additionally, you **must** wear eye protection. A complete eye covering such as goggles are essential and required. There is a very real possibility of glass shards falling from the broken light bulb, which could blind or otherwise injure you. The light bulb should be **cool** to the touch and **not hot**.


Safety gloves are also recommended for this procedure.

Once you have turned off the electricity and put on your goggles to protect your eyes, you may now begin to change the light bulb.




Step 1. Take the supplied **reverse thread adapter** (part 1) and install it on your own handle which should have the same, fairly standard **ACME 3/4-5** threads by twisting normally until very tight. This is designed to be a tight fit on your existing handle. You may need a pair of pliers to tighten.

Step 2. Find the **Broken Light Bulb Remover** (part 3) and screw it onto the supplied **reverse thread adapter** (part 1) by turning **counter-clockwise** until securely fastened.



Step 3. Put on safety goggles and gloves to protect your hands, fingers and eyes from possible glass and cuts.


Step 4. Gently lift and insert the “**Broken Light Bulb Remover**” (part 3) onto the center of the broken light bulb allowing the top to be securely seated inside the broken bulb base. **KEEP THE HANDLE STRAIGHT AND DO NOT LET GO OR OTHERWISE RELEASE THE HANDLE UNDER ANY CIRCUMSTANCE.**



Step 5. Gently twist the handle **counter-clockwise**, thus unscrewing the broken base from the light fixture.

Step 6. Once completely unscrewed, gently and slowly lower the tool staying as vertical as possible to avoid dropping or spilling any potential glass shards.

Failure to follow these steps could result in harm and/or serious injury.





Step 7. Once the handle is lowered gently retrieve the broken light bulb parts and safely discard.
Again, ensure eye and hand protection is worn at all times.

Step 8. Follow **Steps 6 – 9: “INSERTION OF LIGHT BULB TO FIXTURE”** from page 4 and 5 of the instructions.

PLEASE NOTE: *The Broken Light Bulb Remover may not work in every instance. It is intended to work under normal circumstances. If your light bulb was not threaded correctly or otherwise is bent or out of shape, soldered, glued, stuck or otherwise cannot be unscrewed, it may be necessary to call a professional for help.*

Patent Numbers:
US D911,793 S
US 11,417,510 B2

Other Patents Pending

www.thelightbulbchanger.com

LAWRENCE SALES COMPANY, INC.

ALL RIGHTS RESERVED



WARNING

The Light Bulb Changer

This product is intended for use by competent adults only.

This product is not a toy.

The raw materials used in the manufacture of this product have been known to cause cancer and reproductive harm.

For more information go to www.P65WARNING.ca.gov

This product may result in shock, fire, serious injury or possible death if not used properly.

This product was manufactured in the Fujian Province of China,
imported and sold by Lawrence Sales Company, Inc., a Florida Corporation.

This container consists of instructions, a warning sheet, a rubberized lightbulb changer,
a plastic reverse thread adapter, a plastic broken light bulb remover, and two double-sided pieces of tape.



TheLightBulbChanger.com